



BOATRAMP™ INSTALLATION DATA SHEET



Fig. 1



Fig. 2



Fig. 3



Fig. 4



Fig. 5

Made from 100% recycled polyester, Mobi-Mat® range offers the Mobi-Ramp™, the lightest portable roll-out environment friendly mat for creating boat-launches in minutes.

Supplied as a ready-to use kit in a cardboard box, the kit includes one Mobi-Ramp™ roll and the necessary accessories for installation including X-shape connector bar at both mat ends, a staple pack and a pair of gloves.

1. Pre-installation

Prepare the area prior to installation of the mat and level the ground with a rake to clear debris, large stones and foreign objects.

2. Start creating your Mobi-Ramp™:

Unroll the Mobi-Ramp™ and lay it in desired position (Fig. 1).

Check the mat surface and place the corrugated side facing up and the smooth side facing down in contact with the ground.

You can start with aligning one end completely with the cement ramp you are extending it from.

Secure the starting end of the mat while using the U-shaped staples provided (Fig. 2). On a flat terrain, insert staples through the connector holes, as close as possible to the sidewalk/boardwalk so there is no gap.

On a slope or for intense traffic, insert staples through the connector holes and eyelets.

3. Stretch & Anchor your Mobi-Ramp™ down.

Stretch the Mobi-Ramp® from the other end, while using U-shaped staples inserted through the eyelets as tools to gently stretch the mat (Fig. 3).

Secure the mat end by fastening the end with u-shaped staples inserted through the connector with a hammer (Fig. 2).

To secure the mat lengthwise, insert a staple through the eyelet positioned on the lengthwise side of the mat (Fig. 4).

4. Connecting Multiple Mobi-Ramps™

Repeat 1 and 2 (Fig. 1 & 2).

Use end connectors: lay mat ends side by side and then slide the X-shaped connector bar into position to link both mat ends together (Fig. 5).

Repeat 3 (Fig. 3 & 2).

5. Maintenance

Broom or blow is recommended to clean surface.

Once a month, if too much sand accumulates underneath, roll back the mats and level the ground. Then re-do installation.

Optional Mobi-Ramp™ installation

In case of immersion at high tide.

Dig a 4" (10cm) deep and 3" (8cm) wide trench at the end of the Mobi-Ramp™, position the mat end connector straight down at 30 degrees into the sand and anchor the mat down using the U-shaped staples and bury it.

Discover our complete range on www.mobi-mat-chair-beach-access-dms.com

DMS

DESCHAMPS MAT SYSTEMS

218 Little Falls Road, Unit 7
Cedar Grove, NJ 07009, USA
Tel. + 1 973 928 3040
Fax. + 1 973 928 3041

info@mobi-mat-dms.com



DESCHAMPS
SINCE 1860

Usine de Bourisson
BP 40020 - 16400 La Couronne
France
Tel. + 33 (0) 545 677 030
Fax. + 33 (0) 545 678 160
deschamps@deschamps.fr